



COMPUTER CONTROL COMMANDS

A computer control command is composed of an alphabetical command, various parameters, and the terminator that signals the end of the control command.

EXAMPLE: Command to set VFO A to 7 MHz



Commands can be classified as shown below:



For example, note the following in the case of the FA command (Frequency of VFO A):

- To set the frequency to 7 MHz, the following command is sent from the computer to the transceiver:

“FA00007000000;” (Set command)

- To read the frequency of VFO A, the following command is sent from the computer to the transceiver:

“FA;” (Read command)

- When the Read command above has been sent, the following command is returned to the computer:

“FA00007000000;” (Answer command)

Note:

- Do not use the control characters 00 to 1Fh since they are either ignored or cause a “?” answer.
- Program execution may be delayed while turning the **Tuning** control rapidly.
- Receive data is not processed if the frequency is entered from the keypad.

■ **Alphabetical Commands**

A command consists of 2 alphabetical characters. You may use either lower or upper case characters. The commands available for this transceiver are listed in the PC Control Command Tables {page 115}.

■ **Parameters**

Parameters are used to specify information necessary to implement the desired command. The parameters to be used for each command are predetermined. The number of digits assigned to each parameter is also predetermined. Refer to the Computer Control Commands and the PC Control Command Tables {page 115} to configure the appropriate parameters.

When configuring parameters, be careful not to make the following mistakes.

(correct parameter: “IS+1000”)

- IS1000; Not enough parameters specified (No direction given for the IF shift)
- IS+100; Not enough digits (Only three frequency digits given)
- IS □ + □ 1000; Unnecessary characters between parameters
- IS+10000; Too many digits (Five frequency digits given)

Note: If a particular parameter is not applicable to this transceiver, the parameter digits should be filled using any character except the ASCII control codes (00 to 1Fh) and the terminator (;).

■ **Terminator**

To signal the end of a command, it is necessary to use a semicolon (;). The digit where this special character must appear differs depending on the command used.

■ **Error Messages**

In addition to the Answer command, the transceiver can send the following error messages.

Error Message	Reason for Error
?	<ul style="list-style-type: none"> Command syntax was incorrect. Command was not executed due to the current status of the transceiver (even though the command syntax was correct). <p><i>Note: Occasionally this message may not appear due to microprocessor transients in the transceiver.</i></p>
E;	A communication error occurred such as an overrun or framing error during a serial data transmission.
O;	Receive data was sent but processing was not completed.

PC CONTROL COMMAND TABLES

AC	Sets or reads the internal antenna tuner status.										Parameters:
Set	1 2 3 4 5 6 7 8 9 10										P1
	A	C	P1	P2	P3	;					
Read	1 2 3 4 5 6 7 8 9 10										P2
	A	C	;								
Answer	1 2 3 4 5 6 7 8 9 10										P3
	A	C	P1	P2	P3	;					

AG	Sets or reads the AF gain.										Parameters:
Set	1 2 3 4 5 6 7 8 9 10										P1
	A	G	P1	P2	P2	P2	;				
Read	1 2 3 4 5 6 7 8 9 10										P2
	A	G	P1	;							
Answer	1 2 3 4 5 6 7 8 9 10										
	A	G	P1	P2	P2	P2	;				

AI	Sets or reads the Auto Information (AI) function ON/ OFF.										Parameters:
Set	1 2 3 4 5 6 7 8 9 10										P1
	A	I	P1	;							
Read	1 2 3 4 5 6 7 8 9 10										
	A	I	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	A	I	P1	;							

AL	Sets or reads the Auto Notch level.										Parameters:
Set	1 2 3 4 5 6 7 8 9 10										P1
	A	L	P1	P1	P1	;					
Read	1 2 3 4 5 6 7 8 9 10										
	A	L	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	A	L	P1	P1	P1	;					

AM	Sets or reads the Auto Mode ON/ OFF.										Parameters:
Set	1 2 3 4 5 6 7 8 9 10										P1
	A	M	P1	;							
Read	1 2 3 4 5 6 7 8 9 10										
	A	M	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	A	M	P1	;							

21 APPENDIX

AN	Selects the antenna connector ANT1/ ANT2.										Parameters:
Set	1 2 3 4 5 6 7 8 9 10										P1 0: Reads the current antenna selection 1: Selects ANT1 2: Selects ANT2
	A	N	P1	;							
Read	1 2 3 4 5 6 7 8 9 10										
	A	N	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	A	N	P1	;							

AR	Sets or reads the ASC function ON/ OFF. Reports the status of the ASC function.										Parameters:
Set	1 2 3 4 5 6 7 8 9 10										P1 0: Main transceiver 1: Sub-receiver P2 0: ASC OFF 1: ASC ON P3 0: Simplex contact is possible 1: Simplex contact is not possible P2 parameter is valid only to "CTRL" band. When ASC function is OFF, the response is unknown.
	A	R	P1	P2	P3	;					
Read	1 2 3 4 5 6 7 8 9 10										
	A	R	P1	;							
Answer	1 2 3 4 5 6 7 8 9 10										
	A	R	P1	P2	P3	;					

AS	Sets or reads the Auto Mode function parameters.										Parameters:
Set	1 2 3 4 5 6 7 8 9 10										P1 0: HF ~ 50 MHz band 1: 144 MHz band 2: 430/ 440 MHz band 3: 1.2 GHz band P2 00 ~ 99 00 ~ 28: HF ~ 50 MHz band (28 points) 00 ~ 08: 144 MHz, 430/ 440 MHz, 1.2 GHz band (8 points for each band) P3 Frequency in Hz (11-digit) P4 0: Reserved 1: LSB 2: USB 3: CW 4: FM 5: AM 6: FSK 7: CW-R 8: Reserved 9: FSK-R
	A	S	P1	P2	P2	P3	P3	P3	P3	P3	
	11 12 13 14 15 16 17 18 19 20										
	P3	P3	P3	P3	P3	P3	P4	;			
Read	1 2 3 4 5 6 7 8 9 10										
	A	S	P1	P2	P2	;					
Answer	1 2 3 4 5 6 7 8 9 10										
	A	S	P1	P2	P2	P3	P3	P3	P3	P3	
	11 12 13 14 15 16 17 18 19 20										
	P3	P3	P3	P3	P3	P3	P4	;			

BC	Sets or reads the Beat Canceller function status.										Parameters:
Set	1 2 3 4 5 6 7 8 9 10										P1 0: Beat Canceller OFF 1: Auto Beat Canceller ON 2: Manual Beat Canceller ON
	B	C	P1	;							
Read	1 2 3 4 5 6 7 8 9 10										
	B	C	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	B	C	P1	;							

BD	Moves down the frequency band.										Parameters:
Set	1 2 3 4 5 6 7 8 9 10										None
	B	D	;								
Read	1 2 3 4 5 6 7 8 9 10										
Answer	1 2 3 4 5 6 7 8 9 10										

BP	Sets or reads the Manual Beat Canceller frequency settings.										Parameters: P1 000 ~ 063
Set	1	2	3	4	5	6	7	8	9	10	
	B	P	P1	P1	P1	;					
Read	1	2	3	4	5	6	7	8	9	10	
	B	P	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	B	P	P1	P1	P1	;					

BU	Moves up the frequency band.										Parameters: None
Set	1	2	3	4	5	6	7	8	9	10	
	B	U	;								
Read	1	2	3	4	5	6	7	8	9	10	
Answer	1	2	3	4	5	6	7	8	9	10	

BY	Reads the busy signal status.										Parameters: P1 Main transceiver 0: Not busy 1: Busy P2 Sub-receiver 0: Not Busy 1: Busy When the Sky Command function is ON, only the P1 parameter is used.
Set	1	2	3	4	5	6	7	8	9	10	
Read	1	2	3	4	5	6	7	8	9	10	
	B	Y	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	B	Y	P1	P2	;						

CA	Sets and reads the CW AUTO TUNE function status.										Parameters: P1 0: Cancels CW AUTO TUNING function/ Not active 1: Activates CW AUTO TUNING function/ Active
Set	1	2	3	4	5	6	7	8	9	10	
	C	A	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
	C	A	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	C	A	P1	;							

CG	Sets and reads the CARRIER GAIN status.										Parameters: P1 000 (min.) ~ 100 (max.)
Set	1	2	3	4	5	6	7	8	9	10	
	C	G	P1	P1	P1	;					
Read	1	2	3	4	5	6	7	8	9	10	
	C	G	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	C	G	P1	P1	P1	;					

21 APPENDIX

CH	Sets the current frequency to the CALL channel.										Parameters: P1 0: Move the MULTI/ CH control 1 step up 1: Move the MULTI/ CH control 1 step down
Set	1	2	3	4	5	6	7	8	9	10	
	C	H	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
Answer	1	2	3	4	5	6	7	8	9	10	

CI	Sets the current frequency to the CALL channel.										Parameters: None While in VFO mode or Memory recall mode, it sets the frequency to the CALL channel.
Set	1	2	3	4	5	6	7	8	9	10	
	C	I	;								
Read	1	2	3	4	5	6	7	8	9	10	
Answer	1	2	3	4	5	6	7	8	9	10	

CM	Sets or reads the PACKET CLUSTER TUNE function ON/OFF.										Parameters: P1 0: Packet Cluster Tune function OFF 1: Packet Cluster Tune function ON
Set	1	2	3	4	5	6	7	8	9	10	
	C	M	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
	C	M	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	C	M	P1	;							

CN	Sets and reads the CTCSS function.										Parameters: P1 01 ~ 38 Refer to page 35 for the CTCSS tone numbers.
Set	1	2	3	4	5	6	7	8	9	10	
	C	N	P1	P1	;						
Read	1	2	3	4	5	6	7	8	9	10	
	C	N	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	C	N	P1	P1	;						

CT	Sets and reads the CTCSS function status.										Parameters: P1 0: CTCSS function OFF 1: CTCSS function ON
Set	1	2	3	4	5	6	7	8	9	10	
	C	T	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
	C	T	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	C	T	P1	;							

DC	Sets and reads the TX band status.										Parameters: P1 0: Sets TX band to the main transceiver 1: Sets TX band to the sub-receiver ON P2 0: Sets CONTROL band to the main transceiver 1: Sets CONTROL band to the sub-receiver
Set	1 2 3 4 5 6 7 8 9 10										When the P1 parameter changes, the same parameter is set to P2.
	D	C	P1	P2	;						
Read	1 2 3 4 5 6 7 8 9 10										
	D	C	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	D	C	P1	P2	;						

DN	Emulates the microphone DWN key.										Parameters: P1 00 ~ 99
Set	1 2 3 4 5 6 7 8 9 10										If no P1 parameter is specified, the command is interpreted as 1 step down. In Memory mode and Quick Memory mode, the command without a parameter is treated as a Memory channel down command. With parameters, it is treated as the frequency down command.
	D	N	P1	P1	;						
Read	1 2 3 4 5 6 7 8 9 10										
Answer	1 2 3 4 5 6 7 8 9 10										

DQ	Sets and reads the DCS function status.										Parameters: P1 0: DCS function OFF 1: DCS function ON
Set	1 2 3 4 5 6 7 8 9 10										
	D	Q	P1	;							
Read	1 2 3 4 5 6 7 8 9 10										
	D	Q	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	D	Q	P1	;							

EX	Sets or reads the Extension Menu.										Parameters: P1 000 ~ 999: Menu No. (1st) P2 00 ~ 99: Menu No. (2nd) P3 0 ~ 9: Menu No. (3rd) P4 0 ~ 9: Menu No. (4th) P5 A string of characters (Variable length)
Set	1 2 3 4 5 6 7 8 9 10										If the 2nd and 3rd menus are not available, set "00". Specify 1 digit only. Display brightness: EX00000000; (Dimmer OFF). EX00000003; (Dimmer level 2). Menu 29B, 31, 33, 51A ~ E, 59 and 62C have 2-digit parameters. Menu 61C (P5): 000 ~ 999 (3-digit). Menu 62A ~ B (P5): A maximum of 8 characters. Menu 45A (P3): 0 ~ 9 for DTMF Memory channel number. Menu 45A (P4): 0 (DTMF), 1 (Code) Menu 45A (P5): A maximum of 16 digits. If the first character is a space character, the name will be cleared. 62A and 62B become "NO CALL". Although you can turn Menu No. 55 ON, using the EX command, you must use the TC 1; command to turn it OFF.
	E	X	P1	P1	P1	P2	P2	P3	P4	P5	
	11 12 13 14 15 16 17 18 19 20										
	P5	P5	P5	P5	P5	P5	P5	P5	P5	P5	
	21 22 23 24 25 26 27 28 29 30										
Read	1 2 3 4 5 6 7 8 9 10										
	E	X	P1	P1	P1	P2	P2	P3	P4	;	
Answer	1 2 3 4 5 6 7 8 9 10										
	E	X	P1	P1	P1	P2	P2	P3	P4	P5	
	11 12 13 14 15 16 17 18 19 20										
	P5	P5	P5	P5	P5	P5	P5	P5	P5	P5	
	21 22 23 24 25 26 27 28 29 30										
Answer	1 2 3 4 5 6 7 8 9 10										
	P5	P5	P5	P5	P5	;					

21 APPENDIX

Menu No.	Function	EX command parameter P5										
		0	1	2	3	4	5	6	7	8	9	Over
00	Display brightness	OFF	1	2	3	4						
01	Key illumination	OFF	ON									
02	Tuning control change per revolution	500	1000									
03	Tuning with the MULTI/ CH control	OFF	ON									
04	Rounds off VFO frequencies changed by using the MULTI/ CH control	OFF	ON									
05	9 kHz frequency step size for the MULTI/ CH control in AM mode on the AM broadcast band	OFF	ON									
06A	Memory-VFO split operation	OFF	ON									
06B	Tunable (ON) or fixed (OFF) memory channel frequencies	OFF	ON									
07	Program scan partially slowed	OFF	ON									
08	Slow down frequency range for the Program scan	100	200	300	400	500						
09	Program scan hold	OFF	ON									
10	Scan resume method	TO	CO									
11	Visual scan range	31	61	91	181							
12	Beep output level	OFF	1	2	3	4	5	6	7	8	9	
13	TX sidetone volume	OFF	1	2	3	4	5	6	7	8	9	
14	DRU-3A playback volume	OFF	1	2	3	4	5	6	7	8	9	
15	VS-3 playback volume	OFF	1	2	3	4	5	6	7	8	9	
16	Audio output configuration for EXT.SP2 or headphone	0	1	2								
17	Reverses the EXT.SP1 and EXT.SP2 (the headphone jack L/R channels) audio outputs	OFF	ON									
18	Enable an input from the HF RX ANT connector	OFF	ON									
19A	S-meter squelch	OFF	ON									
19B	Hang time for S-meter squelch	OFF	125	250	500							
20	DSP RX equalizer	OFF	H BOOST	F PASS	B BOOST	CONV-EN	USER					
21	DSP TX equalizer	OFF	H BOOST	F PASS	B BOOST	CONV-EN	USER					
22	DSP TX filter bandwidth for SSB or AM	2.0	2.2	2.4	2.6	2.8	3.0					
23	Fine transmit power tuning	OFF	ON									
24	Time-out Timer	OFF	3	5	10	20	30					
25	Transverter frequency display	OFF	ON									
26	TX hold when AT completes the tuning	OFF	ON									
27	In-line AT while receiving	OFF	O1N									
28A	Linear amplifier control delay for HF band	OFF	1	2								
28B	Linear amplifier control delay for 50 MHz band	OFF	1	2								
28C	Linear amplifier control delay for 144 MHz band	OFF	1	2								
28D	Linear amplifier control delay for 430/ 440 MHz band	OFF	1	2								
28E	Linear amplifier control delay for 1.2 GHz band	OFF	1	2								
29A	Repeat the playback	OFF	ON									
29B	Interval time for repeating the playback	0	1	2	3	4	5	6	7	8	9	~ 60 (in steps of 1)
30	Keying priority over playback	OFF	ON									

Menu No.	Function	EX command parameter P5										
		0	1	2	3	4	5	6	7	8	9	Over
31	CW RX pitch/ TX sidetone frequency	400	450	500	550	600	650	700	750	800	850	~ 1000 (in steps of 50)
32	CW rise time	1	2	4	6							
33	CW keying dot, dash weight ratio	AUTO	2.5	2.6	2.7	2.8	2.9	3.0	3.1	3.2	3.3	~ 4.0 (in steps of 0.1)
34	Reverse CW keying auto weight ratio	OFF	ON									
35	Bug key mode	OFF	ON									
36	Auto CW TX in SSB mode	OFF	ON									
37	Frequency correction for changing SSB to CW	OFF	ON									
38	FSK shift	170	200	425	850							
39	FSK keying polarity	NOR- MAL	INVE- RS									
40	FSK tone frequency	1275	2125									
41	Mic gain for FM	LOW	MID	HIGH								
42	Sub-tone mode for FM	BURST	CONT									
43	Auto repeater offset	OFF	ON									
44	TX hold: 1750 Hz tone	OFF	ON									
45A	DTMF number memory select	See the parameter comments.										
45B	TX speed for stored DTMF number	SLOW	FAST									
45C	Pause duration for stored DTMF number	100	250									
45D	Enable Mic remote control	OFF	ON									
46	MAIN/ SUB band: Internal TNC	MAIN	SUB									
47	Data transfer speed: Internal TNC	1200	9600									
48	DCD sensing band	TNC BAND	MAIN- &SUB									
49A	Packet Cluster Tune mode	AUTO	MAN- UAL									
49B	Packet Cluster RX confirmation tone	OFF	MOR- SE	VOICE								
50A	Packet filter bandwidth	OFF	ON									
50B	AF input level for Packet	0	1									
50C	MAIN band AF output level for packet operation	0	1									
50D	SUB band AF output level for packet operation	0	1									
50E	MAIN/ SUB band: External TNC	MAIN	SUB									
50F	Data transfer speed: External TNC	1200	9600									
51A	Front panel PF key	00 ~ 99 (2-digit) 0 ~ 62: Menu No., 63: VOICE1, 64: VOICE2, 65: RX MONI, 66: DSP MONI, 67: QUICK MEMO MR, 68: QUICK MEMO M.IN, 69: SPLIT, 70: TF-SET, 71: A/B, 72: VFO/M, 73: A=B, 74: SCAN, 75: M>VFO, 76: M.IN, 77: CW TUNE, 78: CH1, 79: CH2, 80: CH3, 81: FINE, 82: CLR, 83: CALL, 84: CTRL, 85: 1MHz, 86: ANT1/2, 87: NB, 88: N.R., 89: B.C., 90: A. N., 99: No function										
51B	Microphone PF1 key											
51C	Microphone PF2 key											
51D	Microphone PF3 key											
51E	Microphone PF4 key											
		All menu numbers may not be available (depending on the market code).										
52	Split frequency transfer in master/ slave operation	OFF	ON									
53	Permit to write the transferred Split frequencies to the target VFOs.	OFF	ON									
54	TX inhibit	OFF	ON									
55	Packet communication mode	OFF	ON									

21 APPENDIX

Menu No.	Function	EX command parameter P5										
		0	1	2	3	4	5	6	7	8	9	Over
56	COM port communication speed	4800	9600									
57	APO (Auto Power Off) function	OFF	60									
58	RC-2000 font in easy operation mode	FONT-1	FONT-2									
59	RC-2000 panel/ TS-2000(X) dot-matrix display contrast	1	2									
60	Display mode for RC-2000	NEGATIVE	POSITIVE									
61A	Repeater mode select	OFF	LOCKED	CROSS								
61B	Repeater TX hold	OFF	ON									
61C	Remote control ID code	000 ~ 999 (3-digit number)										
61D	Acknowledgement signal in external remote control mode	OFF	ON									
61E	External remote control	OFF	ON									
62A	Commander callsign for Sky Command II+	A maximum of 9 characters. See page 83.										
62B	Transporter callsign for Sky Command II+	A maximum of 9 characters. See page 83.										
62C	Sky Command II+ tone frequency	See page 35 for the tone number.										
62D	Sky Command II+ communication speed	1200	9600									
62E	Sky Command II+ mode	OFF	CLIENT	COMMAND	TRANSPORTER							

FA	Reads and sets the VFO A frequency.										Parameters: P1 Specify the frequency in Hz (11-digit). For example, 00014195000 for 14.195 MHz. The blank digits must be 0.
	1 2 3 4 5 6 7 8 9 10										
	F	A	P1								
	11	12	13	14	15	16	17	18	19	20	
Set	P1	P1	P1	;							
Read	1 2 3 4 5 6 7 8 9 10										
	F	A	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	F	A	P1								
	11	12	13	14	15	16	17	18	19	20	
	P1	P1	P1	;							

FB	Reads and sets the VFO B frequency.										Parameters: P1 Specify the frequency in Hz (11-digit). For example, 00014195000 for 14.195 MHz. The blank digits must be 0.
	1 2 3 4 5 6 7 8 9 10										
	F	B	P1								
	11	12	13	14	15	16	17	18	19	20	
Set	P1	P1	P1	;							
Read	1 2 3 4 5 6 7 8 9 10										
	F	B	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	F	B	P1								
	11	12	13	14	15	16	17	18	19	20	
	P1	P1	P1	;							

FC	Reads and sets the sub-receiver's VFO frequency.										Parameters: P1 Specify the frequency in Hz (11-digit). For example, 00144195000 for 144.195 MHz. The blank digits must be 0. If the invalid frequency step size is used in the P1 parameter, the transceiver automatically sets the nearest frequency.
	1 2 3 4 5 6 7 8 9 10										
	F	C	P1								
	11	12	13	14	15	16	17	18	19	20	
Set	P1	P1	P1	;							
Read	1 2 3 4 5 6 7 8 9 10										
	F	C	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	F	C	P1								
	11	12	13	14	15	16	17	18	19	20	
	P1	P1	P1	;							

FD	Reads the filter display dot pattern.										Parameters: P1 00000000 ~ FFFFFFFD (32-bit) The filter width display has 30 dots. MSB represents a dot on the left. The last 2 bits are unused. These bits are set to 0.
	1 2 3 4 5 6 7 8 9 10										
	11	12	13	14	15	16	17	18	19	20	
Set											
Read	1 2 3 4 5 6 7 8 9 10										
	F	D	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	F	D	P1								
	11	12	13	14	15	16	17	18	19	20	
	;										

21 APPENDIX

FR	Selects or reads the receiver VFO, M. CH or CALL/ COM.										Parameters: P1 0: VFO A 1: VFO B 2: M.CH 3: CALL The command is applied to the current CTRL (Control) band.
Set	1	2	3	4	5	6	7	8	9	10	
	F	R	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
	F	R	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	F	R	P1	;							

FS	Selects or reads the FINE function status.										Parameters: P1 0: FINE function OFF 1: FINE function ON
Set	1	2	3	4	5	6	7	8	9	10	
	F	S	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
	F	S	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	F	S	P1	;							

FT	Selects or reads the transmitter's VFO, M. CH or CALL/ COM.										Parameters: P1 0: VFO A 1: VFO B 2: M.CH 3: CALL The command is applied to the current TX band.
Set	1	2	3	4	5	6	7	8	9	10	
	F	T	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
	F	T	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	F	T	P1	;							

FW	Selects or reads the DSP receive filter width.										Parameters: P1 0000 ~ 9999 (in Hz) CW: 50, 80, 100, 150, 200, 300, 400, 500, 600, 1000, 2000 FSK: 250, 500, 1000, 1500 FM/AM: 0000=Narrow, 0001=Wide In SSB mode, you cannot use the FW command. Use the SL or SH command instead.
Set	1	2	3	4	5	6	7	8	9	10	
	F	W	P1	P1	P1	P1	;				
Read	1	2	3	4	5	6	7	8	9	10	
	F	W	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	F	W	P1	P1	P1	P1	;				

GT	Selects or reads the AGC constant status.										Parameters: P1 000=OFF 001 (min.) ~ 020 (max.) GT commands cannot be used in FM mode. The transceiver responds with 3 spaces when the GT command is used in FM mode.
Set	1	2	3	4	5	6	7	8	9	10	
	G	T	P1	P1	P1	;					
Read	1	2	3	4	5	6	7	8	9	10	
	G	T	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	G	T	P1	P1	P1	;					

ID	Reads the transceiver ID number.										Parameters: P1 019: TS-2000
	1	2	3	4	5	6	7	8	9	10	
Read	I	D	:								
	1	2	3	4	5	6	7	8	9	10	
Answer	I	D	P1	P1	P1	:					
	1	2	3	4	5	6	7	8	9	10	

IF	Retrieves the transceiver status.										Parameters: P1 Specify the frequency in Hz. (11-digit) The blank digits must be "0". P2 Frequency step size. P3 RIT/ XIT frequency ± 99999 in Hz P4 0: RIT OFF, 1: RIT ON P5 0: XIT OFF, 1: XIT ON P6, P7: Specify the channel bank number. See MC command. P8 0: RX, 1: TX P9 Operating mode. See MD commands for details. P10 See FR and FT commands. P11 Scan status. See SC command. P12 Split operation status. See SP command. P13 0: OFF, 1: TONE, 2: CTCSS, 3: DCS P14 Tone frequency. See TN command. P15 Shift status. See OS command. While operating Sky Command II+, the P2 and P15 parameters become blank. The P2 parameter length changes to 5 bytes and the P3 parameter length becomes 5 bytes.
	Set	1	2	3	4	5	6	7	8	9	
Read	I	F	:								
	1	2	3	4	5	6	7	8	9	10	
Answer	I	F	P1	P1	P1	P1	P1	P1	P1	P1	
	11	12	13	14	15	16	17	18	19	20	
	P1	P1	P1	P2	P2	P2	P2	P3	P3	P3	
	21	22	23	24	25	26	27	28	29	30	
	P3	P3	P3	P4	P5	P6	P7	P7	P8	P9	
	31	32	33	34	35	36	37	38	39	40	
	P10	P11	P12	P13	P14	P14	P15	:			

IS	Sets and reads the IF SHIFT function status.										Parameters: P1 space P2 0400 ~ 1000 (in steps of 50) in CW mode IS commands cannot be used while in SSB, FSK, FM, or AM mode.
	Set	1	2	3	4	5	6	7	8	9	
Read	I	S	:								
	1	2	3	4	5	6	7	8	9	10	
Answer	I	S	P1	P2	P2	P2	P2	:			
	1	2	3	4	5	6	7	8	9	10	

KS	Sets and reads the keying speed of the electric keyer.										Parameters: P1 010 (min.) ~ 060 (max.) [in WPM]
	Set	1	2	3	4	5	6	7	8	9	
Read	K	S	:								
	1	2	3	4	5	6	7	8	9	10	
Answer	K	S	P1	P1	P1	:					
	1	2	3	4	5	6	7	8	9	10	

21 APPENDIX

KY	Converts the characters into Morse code.										Parameters: P1 0: Character buffer is available 1: Character buffer is not available (Answer command only. A space is used for Set command.) P2 Enter characters and numbers Available characters are: ABCDEFGHIJKLMNOPQRSTUVWXYZ _ (space) 0123456789 " ' () * + , - . / : = ?
	Set	1	2	3	4	5	6	7	8	9	
	K	Y	P1	P2							
	11	12	13	14	15	16	17	18	19	20	
	P2	P2	P2	P2	P2	P2	P2	P2	P2	P2	
	21	22	23	24	25	26	27	28	29	30	
	P2	P2	P2	P2	P2	P2	P2	;			
Read	1	2	3	4	5	6	7	8	9	10	
	K	Y	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	K	Y	P1	;							

LK	Sets and reads the key lock function status.										Parameters: P1 0: Lock function OFF (TS-2000/ TS-B2000) 1: F.LOCK function ON (TS-2000/ TS-B2000) 2: A.LOCK function ON (TS-2000/ TS-B2000) P2 0: LOCK function OFF (RC-2000) 1: LOCK function ON (RC-2000)
	Set	1	2	3	4	5	6	7	8	9	
	L	K	P1	P2	;						
Read	1	2	3	4	5	6	7	8	9	10	
	L	K	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	L	K	P1	P2	;						

LM	Sets and reads the DRU-3A unit or electric keyer recording status.										Parameters: P1 0: Stop recording (Set command only) 0: Recording function is inactive 1: Start recording to CH1 2: Start recording to CH2 3: Start recording to CH3
	Set	1	2	3	4	5	6	7	8	9	
	L	M	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
	L	M	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	L	M	P1	;							

LT	Sets and reads the ALT function status.										Parameters: P1 0: ALT function OFF 1: ALT function ON
	Set	1	2	3	4	5	6	7	8	9	
	L	T	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
	L	T	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	L	T	P1	;							

MC	Recalls or reads the Memory channel.										Parameters: P1 _ (space): No bank number 0 ~ 2: Memory bank number P2 00 ~ 99: Channel number Memory channel numbers from 00 to 99 are treated as Memory bank 0. Memory channel numbers from 100 to 199 are treated as Memory bank 1. Memory channel numbers from 200 to 299 are treated as Memory bank 2.
	Set	1	2	3	4	5	6	7	8	9	
	M	C	P1	P2	P2	;					
Read	1	2	3	4	5	6	7	8	9	10	
	M	C	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	M	C	P1	P2	P2	;					

MD	Recalls or reads the operating mode status.										Parameters: P1
Set	1	2	3	4	5	6	7	8	9	10	1: LSB 2: USB 3: CW 4: FM 5: AM 6: FSK 7: CR-R 8: Reserved 9: FSK-R
	M	D	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
	M	D	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	M	D	P1	;							

MF	Sets or reads Menu A or B.										Parameters: P1
Set	1	2	3	4	5	6	7	8	9	10	0: Menu A 1: Menu B
	M	F	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
	M	F	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	M	F	P1	;							

MG	Sets or reads the Microphone gain status.										Parameters: P1
Set	1	2	3	4	5	6	7	8	9	10	000 (min.) ~ 100 (max.)
	M	G	P1	P1	P1	;					
Read	1	2	3	4	5	6	7	8	9	10	
	M	G	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	M	G	P1	P1	P1	;					

ML	Sets or reads the MONITOR function level.										Parameters: P1
Set	1	2	3	4	5	6	7	8	9	10	000: MONITOR OFF 001 (min.) ~ 009 (max.)
	M	L	P1	P1	P1	;					
Read	1	2	3	4	5	6	7	8	9	10	
	M	L	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	M	L	P1	P1	P1	;					

MO	Sets the MONITOR function ON/ OFF in Sky Commander mode.										Parameters: P1
Set	1	2	3	4	5	6	7	8	9	10	0: MONITOR OFF 1: MONITOR ON
	M	O	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
Answer	1	2	3	4	5	6	7	8	9	10	
	M	O	P1	;							

21 APPENDIX

MR	Reads the Memory channel data.										Parameters:	
Set	1 2 3 4 5 6 7 8 9 10										P1 0: RX frequency, 1: TX frequency	
												P2, P3 Bank and channel number. See MC command.
Read	1 2 3 4 5 6 7 8 9 10										P4 Frequency in Hz (11-digit).	
	M	R	P1	P2	P3	P3	;					P5 Mode. See MD command.
Answer	1 2 3 4 5 6 7 8 9 10										P6 Lockout status. 0: Lockout OFF, 1: Lockout ON.	
	M	R	P1	P2	P3	P3	P4	P4	P4	P4		P7 0: OFF, 1: TONE, 2: CTCSS, 3: DCS.
	11 12 13 14 15 16 17 18 19 20										P8 Tone Number. See page 35.	
	P4	P4	P4	P4	P4	P4	P4	P5	P6	P7		P9 CTCSS tone number. See CN command.
	21 22 23 24 25 26 27 28 29 30										P10 DCS code. See QC command.	
	P8	P8	P9	P9	P10	P10	P10	P11	P12	P13		P11 REVERSE status.
	31 32 33 34 35 36 37 38 39 40										P12 SHIFT status. See OS command.	
	P13	P13	P13	P13	P13	P13	P13	P13	P14	P14		P13 Offset frequency. See OS command.
41 42 43 44 45 46 47 48 49 50										P14 Step size. See ST command.		
P15	P16	P16	P16	P16	P16	P16	P16	P16	;		P15 Memory Group number (0 ~ 9).	
										P16 Memory name. A maximum of 8 characters.		
										Memory channel 290 ~ 299: P1=0 (start frequency), P1=1 (end frequency)		

MU	Sets or reads the Memory Group data.										Parameters:	
Set	1 2 3 4 5 6 7 8 9 10										P1 Memory Group 0	
	M	U	P1	P2	P3	P4	P5	P6	P7	P8		P2 Memory Group 1
	11 12 13 14 15 16 17 18 19 20										P3 Memory Group 2	
Read	P9	P10	;									P4 Memory Group 3
	1 2 3 4 5 6 7 8 9 10										P5 Memory Group 4	
Answer	M	U	;									P6 Memory Group 5
	1 2 3 4 5 6 7 8 9 10										P7 Memory Group 6	
Answer	M	U	P1	P2	P3	P4	P5	P6	P7	P8		P8 Memory Group 7
	11 12 13 14 15 16 17 18 19 20										P9 Memory Group 8	
	P9	P10	;									P10 Memory Group 9
										0: Unselected, 1: Selected		

MW	Store the data to the Memory channel.										Parameters:
	1 2 3 4 5 6 7 8 9 10										P1
	M	W	P1	P2	P3	P3	P4	P4	P4	P4	P2, P3
	11 12 13 14 15 16 17 18 19 20										Bank and channel number. See MC command.
	P4	P4	P4	P4	P4	P4	P4	P5	P6	P7	P4
	21 22 23 24 25 26 27 28 29 30										Frequency in Hz (11-digit).
	P8	P8	P9	P9	P10	P10	P10	P11	P12	P13	P5
	31 32 33 34 35 36 37 38 39 40										Mode. See MD command.
	P13	P13	P13	P13	P13	P13	P13	P13	P14	P14	P6
	41 42 43 44 45 46 47 48 49 50										Lockout status. 0: Lockout OFF, 1: Lockout ON
Set	1 2 3 4 5 6 7 8 9 10										P7
	11 12 13 14 15 16 17 18 19 20										0: OFF, 1: TONE, 2: CTCSS, 3: DCS
	P8	P8	P9	P9	P10	P10	P10	P11	P12	P13	P8
	21 22 23 24 25 26 27 28 29 30										Tone Number. See page 35.
	P13	P13	P13	P13	P13	P13	P13	P13	P14	P14	P9
	31 32 33 34 35 36 37 38 39 40										CTCSS tone number. See CN command.
	P15	P16	P16	P16	P16	P16	P16	P16	P16	;	P10
	41 42 43 44 45 46 47 48 49 50										DCS code. See QC command.
	1 2 3 4 5 6 7 8 9 10										P11
	Read	11 12 13 14 15 16 17 18 19 20									
21 22 23 24 25 26 27 28 29 30										P12	
31 32 33 34 35 36 37 38 39 40										SHIFT status. See OS command.	
41 42 43 44 45 46 47 48 49 50										P13	
1 2 3 4 5 6 7 8 9 10										Offset frequency. See OS command.	
11 12 13 14 15 16 17 18 19 20										P14	
21 22 23 24 25 26 27 28 29 30										Step size. See ST command.	
31 32 33 34 35 36 37 38 39 40										P15	
41 42 43 44 45 46 47 48 49 50										Memory Group number (0 ~ 9).	
Answer		1 2 3 4 5 6 7 8 9 10									
	11 12 13 14 15 16 17 18 19 20										Memory name. A maximum of 8 characters.
	21 22 23 24 25 26 27 28 29 30										Memory channel 290 ~ 299:
	31 32 33 34 35 36 37 38 39 40										P1=0 (start frequency), P1=1 (end frequency)
	41 42 43 44 45 46 47 48 49 50										
	1 2 3 4 5 6 7 8 9 10										
	11 12 13 14 15 16 17 18 19 20										
	21 22 23 24 25 26 27 28 29 30										
	31 32 33 34 35 36 37 38 39 40										
	41 42 43 44 45 46 47 48 49 50										

NB	Set or reads the NB (Noise Blanker) function status.										Parameters:
	1 2 3 4 5 6 7 8 9 10										P1
	N	B	P1	;							0: NB OFF
	11 12 13 14 15 16 17 18 19 20										1: NB ON
Set	1 2 3 4 5 6 7 8 9 10										
	N	B	P1	;							
Read	1 2 3 4 5 6 7 8 9 10										
	N	B	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	N	B	P1	;							

NL	Set or reads the NB (Noise Blanker) level.										Parameters:
	1 2 3 4 5 6 7 8 9 10										P1
	N	L	P1	P1	P1	;					001 (min.) ~ 010 (max.)
	11 12 13 14 15 16 17 18 19 20										000 is treated as 001.
Set	1 2 3 4 5 6 7 8 9 10										010 ~ 999 are treated as 010.
	N	L	;								
Read	1 2 3 4 5 6 7 8 9 10										
	N	L	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	N	L	P1	P1	P1	;					

NR	Sets or reads the NR (Noise Reduction) function status.										Parameters:
	1 2 3 4 5 6 7 8 9 10										P1
	N	R	P1	;							0: NR OFF
	11 12 13 14 15 16 17 18 19 20										1: NR1 ON
Set	1 2 3 4 5 6 7 8 9 10										2: NR2 ON
	N	R	;								
Read	1 2 3 4 5 6 7 8 9 10										
	N	R	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	N	R	P1	;							

21 APPENDIX

NT	Sets or reads the Auto Notch function status.										Parameters: P1 0: Auto Notch OFF 1: Auto Notch ON	
	Set	1	2	3	4	5	6	7	8	9		10
		N	T	P1	;							
	Read	1	2	3	4	5	6	7	8	9		10
N		T	;									
Answer	1	2	3	4	5	6	7	8	9	10		
	N	T	P1	;								

OF	Sets or reads the Offset frequency information.										Parameters: P1 000000000 ~ 059950000 in steps of 50000 Offset frequency in Hz (9-digit). Unused digits must be 0.	
	Set	1	2	3	4	5	6	7	8	9		10
		O	F	P1		P1						
		11	12	13	14	15	16	17	18	19		20
	P1	;										
Read	1	2	3	4	5	6	7	8	9	10		
	O	F	;									
Answer	1	2	3	4	5	6	7	8	9	10		
	O	F	P1									
	11	12	13	14	15	16	17	18	19	20		
	P1	;										

OI	Reads the Memory channel data.										Parameters: P1 Specify the frequency in Hz (11 digits) The blank digits must be "0". P2 Frequency step size P3 RIT/ XIT frequency ± 99999 in Hz P4 0: RIT OFF, 1: RIT ON P5 0: XIT OFF, 1: XIT ON P6, P7: Specify the channel bank number. See MC command. P8 0: RX, 1: TX P9 Operating mode. See MD commands for details. P10 See FR and FT commands. P11 Scan status. See SC command. P12 Split operation status. See SP command. P13 0: OFF, 1: TONE, 2: CTCSS, 3: DCS P14 Tone frequency. See TN command. P15 Shift status. See OS command. While operating Sky Command II+, the P2 and P15 parameters become blank. The P2 parameter length changes to 5 bytes and the P3 parameter length becomes 5 bytes.	
	Set	1	2	3	4	5	6	7	8	9		10
	Read	1	2	3	4	5	6	7	8	9		10
O		I	;									
Answer	1	2	3	4	5	6	7	8	9	10		
	O	I	P1	P1	P1	P1	P1	P1	P1	P1		
	11	12	13	14	15	16	17	18	19	20		
	P1	P1	P1	P2	P2	P2	P2	P3	P3	P3		
	21	22	23	24	25	26	27	28	29	30		
	P3	P3	P3	P4	P5	P6	P7	P7	P8	P9		
	31	32	33	34	35	36	37	38	39	40		
P10	P11	P12	P13	P14	P14	P15	;					

OS	Sets or reads the offset function status.										Parameters: P1 0: Simplex 1: + 2: - 3: = (All E-types)
Set	1 2 3 4 5 6 7 8 9 10										Valid only in FM mode. SPLIT function must be OFF.
	O	S	P1	;							
Read	1 2 3 4 5 6 7 8 9 10										
	O	S	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	O	S	P1	;							

PA	Sets or reads the pre-amplifier function status.										Parameters: P1 0: Pre-amplifier OFF (main transceiver) 1: Pre-amplifier ON (main transceiver) P2 (Answer only) 0: Pre-amplifier ON (sub-receiver) 1: Pre-amplifier OFF (sub-receiver)
Set	1 2 3 4 5 6 7 8 9 10										If same frequency band is selected for the main transceiver and the sub-receiver, both pre-amplifiers are turned ON or OFF at the same time.
	P	A	P1	;							
Read	1 2 3 4 5 6 7 8 9 10										
	P	A	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	P	A	P1	P2	;						

PB	Sets or reads the DRU-3A or electric keyer playback status.										Parameters: P1 0: Inactive 1: Playback CH1 2: Playback CH2 3: Playback CH3
Set	1 2 3 4 5 6 7 8 9 10										
	P	B	P1	;							
Read	1 2 3 4 5 6 7 8 9 10										
	P	B	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	P	B	P1	;							

PC	Sets or reads the output power.										Parameters: P1 005 ~ 100 (in steps of 1)
Set	1 2 3 4 5 6 7 8 9 10										Refer to the Specifications for the minimum and maximum power for each operating frequency band and mode. If the power is less than 1 watt, the next power level is used. ex: 2.5 W = 003, 0.5 W= 001
	P	C	P1	P1	P1	;					
Read	1 2 3 4 5 6 7 8 9 10										
	P	C	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	P	C	P1	P1	P1	;					

PI	Stores in the Programable Memory channel.										Parameters: P1 1 ~ 5 (PM channel number)
Set	1 2 3 4 5 6 7 8 9 10										
	P	I	P1	;							
Read	1 2 3 4 5 6 7 8 9 10										
Answer	1 2 3 4 5 6 7 8 9 10										

21 APPENDIX

PK	Reads the Packet Cluster data.										Parameters: This command is used in conjunctin with the AI command.
Set	1	2	3	4	5	6	7	8	9	10	P1 Frequency in Hz (11-digit)
Read	1	2	3	4	5	6	7	8	9	10	P2 Callsign (12-digit)
Answer	1	2	3	4	5	6	7	8	9	10	P3 Comments (20-digit)
	P	K	P1								
	11	12	13	14	15	16	17	18	19	20	
	P1	P1	P1	P2							
	21	22	23	24	25	26	27	28	29	30	
	P2	P2	P2	P2	P2	P3	P3	P3	P3	P3	
	31	32	33	34	35	36	37	38	39	40	
	P3	P3	P3	P3	P3	P3	P3	P3	P3	P3	
	41	42	43	44	45	46	47	48	49	50	
	P3	P3	P3	P3	P3	P4	P4	P4	P4	P4	
	51	52	53	54	55	56	57	58	59	60	
	;										

PL	Sets and reads the Speech Processor input/ output level.										Parameters: P1 Input level: 000 (min.) ~ 100 (max.) P2 Output level: 000 (min.) ~ 100 (max.)
Set	1	2	3	4	5	6	7	8	9	10	P1 Input level: 000 (min.) ~ 100 (max.)
	P	L	P1	P1	P1	P2	P2	P2	;		
Read	1	2	3	4	5	6	7	8	9	10	P2 Output level: 000 (min.) ~ 100 (max.)
	P	L	;								
Answer	1	2	3	4	5	6	7	8	9	10	P1 Input level: 000 (min.) ~ 100 (max.)
	P	L	P1	P1	P1	P2	P2	P2	;		

PM	Recalls the PM (Programmable Memory).										Parameters: P1 0: PM OFF 1 ~ 5 (PM channel number)
Set	1	2	3	4	5	6	7	8	9	10	P1 0: PM OFF 1 ~ 5 (PM channel number)
	P	M	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	P1 0: PM OFF 1 ~ 5 (PM channel number)
	P	M	;								
Answer	1	2	3	4	5	6	7	8	9	10	P1 0: PM OFF 1 ~ 5 (PM channel number)
	P	M	P1	;							

PR	Sets or reads the Speech Processor function ON/ OFF.										Parameters: P1 0: Speech Processor OFF 1: Speech Processor ON
Set	1	2	3	4	5	6	7	8	9	10	P1 0: Speech Processor OFF 1: Speech Processor ON
	P	R	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	P1 0: Speech Processor OFF 1: Speech Processor ON
	P	R	;								
Answer	1	2	3	4	5	6	7	8	9	10	P1 0: Speech Processor OFF 1: Speech Processor ON
	P	R	P1	;							

PS	Sets or reads the Power ON/ OFF status.										Parameters: P1 0: Power ON 1: Power OFF	
Set	1 2 3 4 5 6 7 8 9 10											
	P	S	P1	;								
Read	1 2 3 4 5 6 7 8 9 10											
	P	S	;									
Answer	1 2 3 4 5 6 7 8 9 10											
	P	S	P1	;								

QC	Sets or reads the DCS code.										Parameters: P1 All available 103 DCS codes are numbered sequentially from 000 to 103. ex.: 000: 023 (DCS code) ••• 103: 754 (DCS code)	
Set	1 2 3 4 5 6 7 8 9 10											
	Q	C	P1	P1	P1	;						
Read	1 2 3 4 5 6 7 8 9 10											
	Q	C	;									
Answer	1 2 3 4 5 6 7 8 9 10											
	Q	C	P1	P1	P1	;						

QI	Store the settings in the Quick Memory.										Parameters: None	
Set	1 2 3 4 5 6 7 8 9 10											
	Q	I	;									
Read	1 2 3 4 5 6 7 8 9 10											
Answer	1 2 3 4 5 6 7 8 9 10											

QR	Sets or reads the Quick Memory channel data.										Parameters: P1 0: Quick Memory OFF 1: Quick Memory ON P2 0 ~ 9: Quick Memory channel number	
Set	1 2 3 4 5 6 7 8 9 10											
	Q	R	P1	P2	;							
Read	1 2 3 4 5 6 7 8 9 10											
	Q	R	;									
Answer	1 2 3 4 5 6 7 8 9 10											
	Q	R	P1	P2	;							

RA	Sets or reads the Attenuator function status.										Parameters: P1 00: ATT OFF 01 ~ 99: ATT ON If same frequency band is selected for the main transceiver and the sub-receiver, both attenuators are turned ON or OFF at the same time.	
Set	1 2 3 4 5 6 7 8 9 10											
	R	A	P1	P1	;							
Read	1 2 3 4 5 6 7 8 9 10											
	R	A	;									
Answer	1 2 3 4 5 6 7 8 9 10											
	R	A	P1	P1	P2	P2	;					

21 APPENDIX

RC	Clears the RIT offset frequency.										Parameters: None
Set	1	2	3	4	5	6	7	8	9	10	
	R	C	;								
Read	1	2	3	4	5	6	7	8	9	10	
Answer	1	2	3	4	5	6	7	8	9	10	

RD	Move the RIT offset frequency down. Slow down the scan speed in Scan mode.										Parameters: P1 00000 ~ 99999 (the offset frequency in Hz) P2 1 ~ 9: Scan speed When Scan is OFF: If no parameter is specified, the frequency goes down 1 step. When Scan is ON: RD; to read the current scan speed. RDnnnnn; (nnnnn = Any number) to slow the scan speed 1 step.
Set	1	2	3	4	5	6	7	8	9	10	
	R	D	P1	P1	P1	P1	P1	;			
Read	1	2	3	4	5	6	7	8	9	10	
	R	D	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	R	D	P2	;							

RG	Sets or read the RF gain status.										Parameters: P1 000 (min.) ~ 255 (max.)
Set	1	2	3	4	5	6	7	8	9	10	
	R	G	P1	P1	P1	;					
Read	1	2	3	4	5	6	7	8	9	10	
	R	G	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	R	G	P1	P1	P1	;					

RL	Sets or reads the Noise Reduction level.										Parameters: P1 When the NR1 is ON: 00 = AUTO, 01 ~ 09 When the NR2 is ON: 00 (2 ms) ~ 09 (20 ms) in steps of 2 ms
Set	1	2	3	4	5	6	7	8	9	10	
	R	L	P1	P1	;						
Read	1	2	3	4	5	6	7	8	9	10	
	R	L	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	R	L	P1	P1	;						

RM	Sets or reads the Meter function.										Parameters: P1 Selects the meter scale 0: Unselected 1: SWR 2: COMP 3: ALC P2 Meter value in dots: 0000 ~ 0030
Set	1	2	3	4	5	6	7	8	9	10	
	R	M	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
	R	M	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	R	M	P1	P2	P2	P2	P2	;			

RT	Sets or reads the RIT function status.										Parameters: P1 0: RIT function OFF 1: RIT function ON
Set	1 2 3 4 5 6 7 8 9 10										
	R	T	P1	;							
Read	1 2 3 4 5 6 7 8 9 10										
	R	T	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	R	T	P1	;							

RU	Moves the RIT offset frequency up. Speed up the scan speed in Scan mode.										Parameters: P1 00000 ~ 99999 (the offset frequency in Hz) P2 1 ~ 9: Scan speed When Scan is OFF: If no parameter is specified, the frequency goes 1 step up. When Scan is ON: RU; to read the current scan speed. RUnnnnn; (nnnnn = Any number) to speed the scan speed 1 step up.
Set	1 2 3 4 5 6 7 8 9 10										
	R	U	P1	P1	P1	P1	P1	;			
Read	1 2 3 4 5 6 7 8 9 10										
	R	U	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	R	U	P2	;							

RX	Sets the receiver function status.										Parameters: P1 0: Main transceiver 1: Sub-receiver
Set	1 2 3 4 5 6 7 8 9 10										
	R	X	;								
Read	1 2 3 4 5 6 7 8 9 10										
Answer	1 2 3 4 5 6 7 8 9 10										
	R	X	P1	;							

SA	Sets or reads the Satellite mode status.										Parameters: P1 0: Satellite mode OFF 1: Satellite mode ON P2 0 ~ 9: Satellite Memory Channel number P3 0: Main transceiver (uplink)/ Sub-receiver (downlink) 1: Main transceiver (downlink)/ Sub-receiver (uplink) P4 0: CTRL is on the main transceiver 1: CTRL is on the sub-receiver P5 0: TRACE OFF, 1: TRACE ON P6 0: TRACE REV. OFF, 1: TRACE REV ON P7 0: MULTI/ CH control (VFO mode) 1: MULTI/ CH control (Memory channel) P8 Satellite Channel name (8 characters) Use the FA (downlink) or FB (uplink) command to change the frequencies.
Set	1 2 3 4 5 6 7 8 9 10										
	S	A	P1	P2	P3	P4	P5	P6	P7	;	
Read	1 2 3 4 5 6 7 8 9 10										
	S	A	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	S	A	P1	P2	P3	P4	P5	P6	P7	P8	
	11 12 13 14 15 16 17 18 19 20										
	P8	P8	P8	P8	P8	P8	P8	P8	;		

21 APPENDIX

SB	Sets or reads the SUB, TF-W status.										Parameters: P1 0: SUB (TF-W) OFF 1: SUB (TF-W) ON	
	Set	1	2	3	4	5	6	7	8	9		10
		S	B	P1	;							
	Read	1	2	3	4	5	6	7	8	9		10
	S	B	;									
Answer	1	2	3	4	5	6	7	8	9	10		
	S	B	P1	;								

SC	Sets or reads the SCAN function status.										Parameters: P1 0: Scan OFF 1: Scan ON 2: MHz Scan ON 3: Visual Scan ON 4: Tone Scan ON 5: CTCSS Scan ON 6: DCS Scan ON	
	Set	1	2	3	4	5	6	7	8	9		10
		S	C	P1	;							
	Read	1	2	3	4	5	6	7	8	9		10
	S	C	;									
Answer	1	2	3	4	5	6	7	8	9	10		
	S	C	P1	;								

SD	Sets or reads the CW break-in time delay.										Parameters: P1 0000 ~ 1000 ms (in steps of 50 ms) 0000 is FBK (Full break-in)	
	Set	1	2	3	4	5	6	7	8	9		10
		S	D	P1	P1	P1	P1	;				
	Read	1	2	3	4	5	6	7	8	9		10
	S	D	;									
Answer	1	2	3	4	5	6	7	8	9	10		
	S	D	P1	P1	P1	P1	;					

SH	Sets or reads the DSP filter settings.										Parameters: P1 00 ~ 11 SSB/ FM (Hz) 00: 1400, 01: 1600, 02: 1800, 03: 2000, 04: 2200, 05: 2400, 06: 2600, 07: 2800, 08: 3000, 09: 3400, 10: 4000, 11: 5000 AM (Hz) 00: 2500, 01: 3000, 02: 4000, 03: 5000 When the Packet Filter (Menu No. 50A) is ON, 00: 170 Hz, 01: 1930, 02: 2160, 03: PSK	
	Set	1	2	3	4	5	6	7	8	9		10
		S	H	P1	P1	;						
	Read	1	2	3	4	5	6	7	8	9		10
	S	H	;									
Answer	1	2	3	4	5	6	7	8	9	10		
	S	H	P1	P1	;							

SI	Enters the Satellite memory name.										Parameters: P1 0 ~ 9 (Channel number) P2 Satellite memory channel name (A maximum of 8 characters)	
	Set	1	2	3	4	5	6	7	8	9		10
		S	I	P1	P2	P2	P2	P2	P2	P2		P2
		11	12	13	14	15	16	17	18	19		20
	P2	;										
Read	1	2	3	4	5	6	7	8	9	10		
Answer	1	2	3	4	5	6	7	8	9	10		

SL	Sets or reads the DSP filter settings.										Parameters: P1 00 ~ 11 SSB/ FM (Hz) 00: 10 (0), 01: 50, 02: 100, 03: 200, 04: 300, 05: 400, 06: 500 07: 600, 08: 700, 09: 800, 10: 900, 11: 1000 AM (Hz) 00: 10 (0), 01: 100, 02: 200, 03: 500									
Set	1	2	3	4	5	6	7	8	9	10										
Read	1	2	3	4	5	6	7	8	9	10	S	L	;							
Answer	1	2	3	4	5	6	7	8	9	10	S	L	P1	P1	;					
											When the Packet Filter (Menu No. 50A) is ON, 00: WIDE, 01: NAR									

SM	Reads the S-meter status.										Parameters: P1 0: Main transceiver 1: Sub-receiver 2: Main transceiver S-meter level 3: Sub-receiver S-meter level P2 Meter readings 0000 ~ 0030 (Main transceiver) 0000 ~ 0015 (Sub-receiver)									
Set	1	2	3	4	5	6	7	8	9	10										
Read	1	2	3	4	5	6	7	8	9	10	S	M	P1	;						
Answer	1	2	3	4	5	6	7	8	9	10	S	M	P1	P2	P2	P2	P2	;		

SQ	Sets and reads the squelch level.										Parameters: P1 0: Main transceiver 1: Sub-receiver P2 Squelch level 000 ~ 255									
Set	1	2	3	4	5	6	7	8	9	10	S	Q	P1	P2	P2	P2	;			
Read	1	2	3	4	5	6	7	8	9	10	S	Q	P1	;						
Answer	1	2	3	4	5	6	7	8	9	10	S	Q	P1	P2	P2	P2	;			

SR	Resets the transceiver.										Parameters: P1 1: VFO reset 2: Master reset									
Set	1	2	3	4	5	6	7	8	9	10	S	R	P1	;						
Read	1	2	3	4	5	6	7	8	9	10										
Answer	1	2	3	4	5	6	7	8	9	10										

SS	Sets or reads the Program Scan pause frequency.										Parameters: P1 0: Reserved 1: Set 2: All clear									
Set	1	2	3	4	5	6	7	8	9	10	S	S	P1	;						
Read	1	2	3	4	5	6	7	8	9	10	S	S	;							
Answer	1	2	3	4	5	6	7	8	9	10	S	S	P1	;						
											When selecting memory channel 290 ~ 299, use the DN or UP command to set the frequency. Then, use this command to set the Program Scan pause frequency. Using the IF command, you can read the current frequency.									

21 APPENDIX

ST	Sets or reads the MULTI/ CH control frequency steps.										Parameters:
Set	1 2 3 4 5 6 7 8 9 10										P1 SSB/ CW/ FSK mode: 00 ~ 03 00: 1 kHz, 01: 2.5 kHz, 02: 5 kHz, 03: 10 kHz AM/ FM mode: 00 ~ 09 00: 5 kHz, 01: 6.25 kHz, 02: 10 kHz, 03: 12.5 kHz, 04: 15 kHz, 05: 20 kHz, 06: 25 kHz, 07: 30 kHz, 08: 50 kHz, 09: 100 kHz
	S	T	P1	P1	;						
Read	1 2 3 4 5 6 7 8 9 10										
	S	T	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	S	T	P1	P1	;						

SU	Sets or reads the Program Scan pause frequency.										Parameters:
Set	1 2 3 4 5 6 7 8 9 10										P1 0: Program Scan group 1: Memory Scan group P2 Group 0. 0: Unselected, 1 ~ 9: Selected P3 Group 1. 0: Unselected, 1 ~ 9: Selected P4 Group 2. 0: Unselected, 1 ~ 9: Selected P5 Group 3. 0: Unselected, 1 ~ 9: Selected P6 Group 4. 0: Unselected, 1 ~ 9: Selected P7 Group 5. 0: Unselected, 1 ~ 9: Selected P8 Group 6. 0: Unselected, 1 ~ 9: Selected P9 Group 7. 0: Unselected, 1 ~ 9: Selected P10 Group 8. 0: Unselected, 1 ~ 9: Selected P11 Group 9. 0: Unselected, 1 ~ 9: Selected
	S	U	P1	P2	P3	P4	P5	P6	P7	P8	
	11 12 13 14 15 16 17 18 19 20										
	P9	P10	P11	;							
Read	1 2 3 4 5 6 7 8 9 10										
	S	U	P1	;							
Answer	1 2 3 4 5 6 7 8 9 10										
	S	U	P1	P2	P3	P4	P5	P6	P7	P8	
	11 12 13 14 15 16 17 18 19 20										
	P9	P10	P11	;							

SV	Execute the Memory Transfer function.										Parameters:
Set	1 2 3 4 5 6 7 8 9 10										No parameter
	S	V	;								
Read	1 2 3 4 5 6 7 8 9 10										
Answer	1 2 3 4 5 6 7 8 9 10										

TC	Sets or reads the internal TNC mode.										Parameters:
Set	1 2 3 4 5 6 7 8 9 10										P1 _ (space) is used P2 0: Packet communication mode 1: PC Control command mode Key in "TC 0" to enter Packet communication mode. Key in "TC 1" to return to PC Control command mode.
	T	C	P1	P2	;						
Read	1 2 3 4 5 6 7 8 9 10										
	T	C	;								
Answer	1 2 3 4 5 6 7 8 9 10										
	T	C	P1	P2	;						

TD	Sends the DTMF memory channel data.										Parameters: P1 00 ~ 09 (DTMF memory channel number)
Set	1	2	3	4	5	6	7	8	9	10	If no data is stored in the channel, no data is sent.
	T	D	P1	P1	;						
Read	1	2	3	4	5	6	7	8	9	10	
Answer	1	2	3	4	5	6	7	8	9	10	

TI	Reads the TNC LED status.										Parameters: P1 0: 9.6k LED is OFF, 1: 9.6k LED is ON P2 0: STA LED is OFF, 1: STA LED is ON P3 0: CON LED is OFF, 1: CON LED is ON
Set	1	2	3	4	5	6	7	8	9	10	
Read	1	2	3	4	5	6	7	8	9	10	
	T	I	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	T	I	P1	P2	P3	;					

TN	Sets or reads the sub-tone frequency.										Parameters: P1 01 ~ 39 Refer to page 35 for the tone numbers.
Set	1	2	3	4	5	6	7	8	9	10	
	T	N	P1	P1	;						
Read	1	2	3	4	5	6	7	8	9	10	
	T	N	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	T	N	P1	P1	;						

TO	Sets or reads the TONE function ON/ OFF.										Parameters: P1 0: TONE OFF 1: TONE ON 2: Emulates switching TONE ON (Set only) 3: Emulates switching TONE OFF (Set only)
Set	1	2	3	4	5	6	7	8	9	10	
	T	O	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
	T	O	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	T	O	P1	;							

TS	Sets or reads the TF-SET function status.										Parameters: P1 0: TF-SET OFF 1: TF-SET ON When the transceiver is operating in simplex mode. P1 0: REVERSE ON 1: REVERSE OFF Every time you send TS1; the REVERSE function toggles.
Set	1	2	3	4	5	6	7	8	9	10	
	T	S	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
	T	S	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	T	S	P1	;							

21 APPENDIX

TX	Sets the transceiver in TX mode.										Parameters: P1 0: Transmits on the main transceiver's frequency band 1: Transmits on the sub-receiver's frequency band
Set	1	2	3	4	5	6	7	8	9	10	
	T	X	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
Answer	1	2	3	4	5	6	7	8	9	10	
	T	X	P1	;							

TY	Sets or reads the microprocessor firmware type.										Parameters: P1 Reserved P2 0: Overseas type 1: Japanese 100 W type 2: Japanese 20 W type
Set	1	2	3	4	5	6	7	8	9	10	
Read	1	2	3	4	5	6	7	8	9	10	
	T	Y	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	T	Y	P1	P1	P2	;					

UL	Detects the PLL unlock status.										Parameters: P1 0: Lock 1: Unlock
Set	1	2	3	4	5	6	7	8	9	10	
Read	1	2	3	4	5	6	7	8	9	10	
Answer	1	2	3	4	5	6	7	8	9	10	
	U	L	P1	;							

UP	Emulates the microphone UP key.										Parameters: P1 00 ~ 99 If no P1 parameter is specified, the command is interpreted as 1 step up. In Memory mode and Quick Memory mode, commands without parameters are treated as Memory channel up commands. With parameters, they are treated as frequency up commands.
Set	1	2	3	4	5	6	7	8	9	10	
	U	P	P1	P1	;						
Read	1	2	3	4	5	6	7	8	9	10	
Answer	1	2	3	4	5	6	7	8	9	10	

VD	Sets or reads the VOX delay time.										Parameters: P1 0000 ~ 3000 ms (in steps of 150)
Set	1	2	3	4	5	6	7	8	9	10	
	V	D	P1	P1	P1	P1	;				
Read	1	2	3	4	5	6	7	8	9	10	
	V	D	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	V	D	P1	P1	P1	P1	;				

VG	Sets or reads the VOX GAIN.										Parameters: P1 000 ~ 009
Set	1	2	3	4	5	6	7	8	9	10	
	V	G	P1	P1	P1	;					
Read	1	2	3	4	5	6	7	8	9	10	
	V	G	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	V	G	P1	P1	P1	;					

VR	Emulates the VOICE1 or VOICE2 key.										Parameters: P1 0: VOICE1 1: VOICE2
Set	1	2	3	4	5	6	7	8	9	10	
	V	R	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
Answer	1	2	3	4	5	6	7	8	9	10	

VX	Sets or reads the VOX function status.										Parameters: P1 0: VOX OFF 1: VOX ON
Set	1	2	3	4	5	6	7	8	9	10	
	V	X	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
	V	X	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	V	X	P1	;							

XT	Sets or reads the XIT function status.										Parameters: P1 0: XIT OFF 1: XIT ON
Set	1	2	3	4	5	6	7	8	9	10	
	X	T	P1	;							
Read	1	2	3	4	5	6	7	8	9	10	
	X	T	;								
Answer	1	2	3	4	5	6	7	8	9	10	
	X	T	P1	;							

KENWOOD