

```
Public Class Form1
```

```
'povinné deklarace použitých proměnných
```

```
Dim Povel As String = "MD02;"
```

```
Dim Fvfoa As String = "FA014074000;" 'proměnná nemusí být v tomto programu použita, v jiných do ní čtu frekvenci VFO-A z FT-710
```

```
Dim jmenoportu As String = "COM3"
```

```
Dim br1 As Integer = 38400
```

```
Dim Text1 As String = "FT-710: " 'pomocná proměnná k tvorbě Text v záhlaví Form1
```

```
'procedura Form1, obsahuje instrukce provedené po Load
```

```
Private Sub Form1_Load(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles MyBase.Load
```

```
SerialPort1.PortName = jmenoportu
```

```
SerialPort1.BaudRate = br1
```

```
Nastav_com()
```

```
End Sub
```

```
'Následují základní procedury pro posílání povelu a pro konfiguraci portu COMxx
```

```
Private Sub Posli_Povel()
```

```
SerialPort1.Close() 'když se dvakrát za sebou otevře, tak se to zesere, tak ho zavírám
```

```
SerialPort1.Open() 'otevření serial portu
```

```
Dim bajty() As Byte = System.Text.Encoding.ASCII.GetBytes(Povel)
```

```
'převede Povel na bajty
```

```
SerialPort1.BaseStream.Write(bajty, 0, Povel.Length)
```

```
'odešle skrz serial port bajty, začátek = 0, délka
```

```
SerialPort1.BaseStream.Flush()
```

```
'toto je v programu kvůli Yaesu, aby šel celý stream najednou
```

```
Threading.Thread.Sleep(300)
```

```
'taky kvůli Yaesu podle modelu upravit
```

```
Fvfoa = SerialPort1.ReadExisting()
```

```
'přečte vše, co je v bufferu, tedy to, na co TCVR odpovídá
```

```
'například proměnná Fvfoa je naplněna hodnotou aktuální frekvence po odeslání "FA;", tento program Fvfoa nikde nevyužívá
```

```
SerialPort1.Close()
```

```
End Sub
```

```
Private Sub Nastav_com() 'nastavování sériových portů
```

```
SerialPort1.Close() 'na otevřeném portu nelze měnit parametry
```

```
SerialPort1.PortName = jmenoportu
```

```
SerialPort1.BaudRate = br1
```

```
End Sub
```

'Od tohoto místa začínají instrukce k nastavení SerialPort1

```
Private Sub COM3ToolStripMenuItem_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles COM3ToolStripMenuItem.Click
    jmenoportu = "COM3"
    Text = Text1 + jmenoportu + ", " + "Baud: " + CStr(br1)
    Nastav_com()
End Sub
```

```
Private Sub COM4ToolStripMenuItem_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles COM4ToolStripMenuItem.Click
    jmenoportu = "COM4"
    Text = Text1 + jmenoportu + ", " + "Baud: " + CStr(br1)
    Nastav_com()
End Sub
```

```
Private Sub COM11ToolStripMenuItem_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles COM11ToolStripMenuItem.Click
    jmenoportu = "COM11"
    Text = Text1 + jmenoportu + ", " + "Baud: " + CStr(br1)
    Nastav_com()
End Sub
```

```
Private Sub Baud38400ToolStripMenuItem_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles Baud38400ToolStripMenuItem.Click
    br1 = 38400
    Text = Text1 + jmenoportu + ", " + "Baud: " + CStr(br1)
    Nastav_com()
End Sub
```

```
Private Sub Baud19200ToolStripMenuItem_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles Baud19200ToolStripMenuItem.Click
    br1 = 19200
    Text = Text1 + jmenoportu + ", " + "Baud: " + CStr(br1)
    Nastav_com()
End Sub
```

```
Private Sub Baud9600ToolStripMenuItem_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles Baud9600ToolStripMenuItem.Click
    br1 = 9600
    Text = Text1 + jmenoportu + ", " + "Baud: " + CStr(br1)
    Nastav_com()
End Sub
```

'Od tohoto místa začínají procedury, které konají po kliknutí položky z menu
'Procedury dělají jednoduché věci, zejména dosadí do Povel řetězec s požadovanou instrukcí a následně pošlou povel do TCVRu

```
Private Sub IP0ToolStripMenuItem1_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles IP0ToolStripMenuItem1.Click
    Povel = "PA00;"
    Posli_Povel()
End Sub
```

```
Private Sub AMP1ToolStripMenuItem_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles AMP1ToolStripMenuItem.Click
    Povel = "PA01;"
    Posli_Povel()
End Sub
```

```
Private Sub AMP2ToolStripMenuItem_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles AMP2ToolStripMenuItem.Click
    Povel = "PA02;"
    Posli_Povel()
End Sub
```

```
Private Sub ATT6DBToolStripMenuItem_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles ATT6DBToolStripMenuItem.Click
    Povel = "RA01;"
    Posli_Povel()
End Sub
```

```
Private Sub ATT12DBToolStripMenuItem_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles ATT12DBToolStripMenuItem.Click
    Povel = "RA02;"
    Posli_Povel()
End Sub
```

```
Private Sub ATT18DBToolStripMenuItem_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles ATT18DBToolStripMenuItem.Click
    Povel = "RA03;"
    Posli_Povel()
End Sub
```

```
Private Sub ATTOFFToolStripMenuItem_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles ATTOFFToolStripMenuItem.Click
    Povel = "RA00;"
    Posli_Povel()
End Sub
```

```
Private Sub WToolStripMenuItem_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles WToolStripMenuItem.Click
    Povel = "PC010;"
    Posli_Povel()
End Sub
```

```
Private Sub WToolStripMenuItem1_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles WToolStripMenuItem1.Click
    Povel = "PC030;"
    Posli_Povel()
End Sub
```

```
Private Sub WToolStripMenuItem2_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles WToolStripMenuItem2.Click
    Povel = "PC050;"
    Posli_Povel()
End Sub
```

```
Private Sub WToolStripMenuItem3_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles WToolStripMenuItem3.Click
    Povel = "PC080;"
    Posli_Povel()
End Sub
```

```
Private Sub RadioONToolStripMenuItem_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles RadioONToolStripMenuItem.Click
    Povel = "PS1;"
    Posli_Povel()
End Sub
```

```
Private Sub RadioOFFToolStripMenuItem_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles RadioOFFToolStripMenuItem.Click
    Povel = "PS0;"
    Posli_Povel()
End Sub
```

'Od tohoto místa začínají procedury, které otevřou webové stránky webu sidlo.com

```
Private Sub AboutYaesuFT710ToolStripMenuItem_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles AboutYaesuFT710ToolStripMenuItem.Click
```

```
    Dim psi As New ProcessStartInfo With {
        .FileName = "https://www.sidlo.com/FT_710/index.htm",
        .UseShellExecute = True
    }
    Process.Start(psi)
End Sub
```

```
Private Sub WwwsidlocomToolStripMenuItem_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles WwwsidlocomToolStripMenuItem.Click
```

```
    Dim psi As New ProcessStartInfo With {
        .FileName = "https://www.sidlo.com/",
        .UseShellExecute = True
    }
    Process.Start(psi)
End Sub
```

```
Private Sub AboutToolStripMenuItem_Click(ByVal sender As System.Object, ByVal e As System.EventArgs) Handles AboutToolStripMenuItem.Click
```

```
    Dim psi As New ProcessStartInfo With {
        .FileName = "https://www.sidlo.com/Accessories/CAT_CI_V/CAT.htm",
        .UseShellExecute = True
    }
    Process.Start(psi)
End Sub
End Class
```